



# Illumina DRAGEN Server v4

## Site Prep and Installation Guide

ILLUMINA PROPRIETARY  
Document #200015717 v01  
July 2022

**For Research Use Only. Not for use in diagnostic procedures.**

This document and its contents are proprietary to Illumina, Inc. and its affiliates ("Illumina"), and are intended solely for the contractual use of its customer in connection with the use of the product(s) described herein and for no other purpose. This document and its contents shall not be used or distributed for any other purpose and/or otherwise communicated, disclosed, or reproduced in any way whatsoever without the prior written consent of Illumina. Illumina does not convey any license under its patent, trademark, copyright, or common-law rights nor similar rights of any third parties by this document.

The instructions in this document must be strictly and explicitly followed by qualified and properly trained personnel in order to ensure the proper and safe use of the product(s) described herein. All of the contents of this document must be fully read and understood prior to using such product(s).

FAILURE TO COMPLETELY READ AND EXPLICITLY FOLLOW ALL OF THE INSTRUCTIONS CONTAINED HEREIN MAY RESULT IN DAMAGE TO THE PRODUCT(S), INJURY TO PERSONS, INCLUDING TO USERS OR OTHERS, AND DAMAGE TO OTHER PROPERTY, AND WILL VOID ANY WARRANTY APPLICABLE TO THE PRODUCT(S).

ILLUMINA DOES NOT ASSUME ANY LIABILITY ARISING OUT OF THE IMPROPER USE OF THE PRODUCT(S) DESCRIBED HEREIN (INCLUDING PARTS THEREOF OR SOFTWARE).

© 2022 Illumina, Inc. All rights reserved.

All trademarks are the property of Illumina, Inc. or their respective owners. For specific trademark information, see [www.illumina.com/company/legal.html](http://www.illumina.com/company/legal.html).

# Table of Contents

<b>Overview</b> .....	<b>1</b>
<b>Site Preparation</b> .....	<b>2</b>
Delivery and Setup .....	2
Facility Requirements .....	3
Electrical Requirements .....	3
Environmental Considerations .....	4
<b>Safety &amp; Compliance</b> .....	<b>7</b>
Safety Considerations and Markings .....	7
Compliance and Regulatory Markings .....	7
<b>Set Up the DRAGEN Server</b> .....	<b>8</b>
Mount the Server .....	8
Server Ports .....	12
Install the Illumina DRAGEN Server License .....	12
Shut Down the Server .....	13
<b>Configure Settings</b> .....	<b>14</b>
Security and Safety .....	14
Network Considerations .....	15
<b>Resources &amp; References</b> .....	<b>20</b>
Revision History .....	21

# Overview

This resource provides instructions for setting up the Illumina® DRAGEN Server™, including preparing your site for installation and operation.

**!** | The CentOS Project will discontinue support of CentOS 7 on June 30, 2024. As a result, support for CentOS 7 on the DRAGEN Servers will end. Upgrade the operating system to Oracle 8 to continue to use future versions of the DRAGEN Server software. Refer to the Upgrade to Oracle 8 instructions on [support.illumina.com/bulletins.html](https://support.illumina.com/bulletins.html). Contact Illumina Technical Support for additional help.

Use the following specifications and guidelines included to prepare your facility:

- Space requirements
- Electrical requirements
- Environmental considerations
- Computing requirements
- Network considerations

## Server Specifications

Component	Specifications
CPU	Dual Intel Xeon Gold 6226R 2.9GHz, 16C / 32T
System Memory	512 GB DDR4
Scratch Drive	2 x 6.4 TB NVMe U.2 SSD
OS Drive	512 GB SATAIII SSD

# Site Preparation

This section provides specifications and guidelines for preparing your site for installation and operation of the DRAGEN Server.

- Laboratory space requirements
- Electrical requirements
- Environmental considerations

## Delivery and Setup

The DRAGEN Server is unpacked and installed by the customer. The space must be ready before delivery.

### Box Dimensions

Use the following dimensions to determine transport, setup, and storage plans.

Measurement	Dimension
Height	29.5 cm (11.6 in)
Width	62 cm (24.4 in)
Depth	96 cm (37.8 in)
Weight	34.8 kg (77 lb)

### Shipping Box Components

The DRAGEN Server and components are shipped in one box. The following components are included:

- Power cord, country-specific
- DRAGEN Server License USB key
- Rack mount rails - 80.0 cm (31.5 in) length
- Rack mount screws
- Two SFP+ transceivers

## Facility Requirements

Use the specifications and requirements provided in this section to set up your lab space.

### Equipment Dimensions

Measurement	Dimension
Height	8.8 cm (3.46 in)
Width	43.8 cm (17.24 in)
Depth	76.0 cm (29.924 in)
Weight	23 kg (50.7 lb)

### Rack Requirements

Minimum Depth	60.95cm (25 in)
Maximum Depth	89.7cm (35.4 in)

**!** If the rack used is shorter than the length of the server, 29.9 in, or the rails, 31.5 in, then the server and rails will extend beyond the length of the rack and may interfere with existing power and cable management along with the proper closure of the rack. Consider using a rack that is 29 in-depth or larger.

### Placement Requirements

Position the DRAGEN Server to allow proper ventilation, access to one power outlet, and access for servicing.

- Allow a rack height of at least 2U.
- Make sure that there is one standard pocket outlet within 10 ft (3 m) of the server.
- Position the instrument so personnel can quickly disconnect the power cords from the outlets.

## Electrical Requirements

### Power Specifications

Type	Specification
Line voltage	100–240 VAC at 47/63 Hz
Peak power consumption	750 Watts
Power supply rating	2000 Watts at 100%

For 100–240 Volts AC, your facility must be wired with a minimum 15 Amp grounded line with proper voltage. An electrical ground is required. If the voltage fluctuates more than 10%, a power line regulator is required.

The server must be connected to a dedicated circuit that must not be shared with any other equipment.

## Receptacles

Your facility must be wired with the following receptacles:

- For 100–110 Volts AC—Two 10 amp grounded, dedicated lines with proper voltage and electrical ground.
- For 220–240 Volts AC—Two 6 amp grounded lines with proper voltage and electrical ground.
- North America and Japan—NEMA 5–15.
- If the voltage fluctuates more than 10%, power line regulators are required.

## Protective Earth



The DRAGEN Server has a connection to protective earth through the enclosure. The safety ground on the power cord returns protective earth to a safe reference. The protective earth connection on the power cord must be in good working condition when using this device.

## Power Cords

The instrument comes with an international standard IEC 60320 C20 receptacle, and is shipped with a region-specific power cord. To obtain equivalent receptacles or power cords that comply with local standards, consult a third-party supplier such as Interpower Corporation ([www.interpower.com](http://www.interpower.com)). All power cords are 2.5 m (8 ft) in length.

Hazardous voltages are removed from the instrument only when the power cord is disconnected from the AC power source. Position the server so that you can quickly disconnect the power cord from the outlet.

## Fuses

The server contains no user-replaceable fuses.

# Environmental Considerations

The following table specifies temperature, humidity, and other environmental considerations for safely housing the instrument.

Element	Specification
Temperature	Maintain a server room temperature of 0°C to 35°C. This temperature is the operating temperature of the DRAGEN Server. Do not allow the ambient temperature to vary by more than $\pm 2^\circ\text{C}$ .
Humidity	Maintain a noncondensing relative humidity between 10–85%.
Altitude	Locate the DRAGEN Server at an altitude below 2,000 meters (6,500 ft).
Air Quality	Operate the server in a data center environment with air filtration per ISO 14644-1 Class 8 with a 95% upper confidence limit.
Ventilation	Consult your facilities department for ventilation requirements sufficient for the level of heat output expected from the DRAGEN Server.
Location	Operate the server in an indoor environment only. The server is not suitable for use in locations where children are likely to be present. The server is intended for use in a server room.

## Heat Output

Measured Power	Thermal Output
800 Watts	2800 BTU/hr

## Noise Output

Acoustical Performance	Noise Output (dB)	Distance from Server
Idle @ 25°C ambient	70	1 meter (3.3 feet)
Maximum load @ 25°C ambient	76	1 meter (3.3 feet)

## Uninterruptible Power Supply

Illumina recommends using a user-supplied uninterruptible power supply (UPS).

Illumina is not responsible for data loss caused by interrupted power, regardless of whether the DRAGEN Server is connected to a UPS. Standard generator-backed power is often not uninterruptible, so a brief power outage occurs before power resumes. This power outage interrupts analysis and data transfer.

The following table shows three example recommended UPS models for the DRAGEN Server.

Specification	North America APC Model # SMT3000RM2U	Japan APC Model # SMT3000RMJ2U	International APC Model # SMT3000RMI2U
Maximum Output Capacity	2700 W 2880 VA	2400 W 2400 VA	2700 W 3000 VA
Input Voltage (Nominal)	120 VAC	100 VAC	230 VAC
Input Frequency	50/60 Hz	50/60 Hz	50/60 Hz
Input Connection	NEMA L5-30P	NEMA L5-30P	BS1363A British IEC 320 C20 Schuko CEE 7 / EU1-16P
Built-In UPS Output Receptacles	3xNEMA 5-15R 3xNEMA 5-20R 1xNEMA L5-30R	3xNEMA 5-15R 3xNEMA 5-20R 1xNEMA L5-30R	8xIEC 320 C13 3xIEC Jumpers 1xIEC 320 C19
Dimensions	8.5 cm x 43.2 cm x 66.7 cm (3.35 in x 17.01 in x 26.26 in)	8.7 cm x 43.2 cm x 66.7 cm	8.6 cm x 48 cm x 68.3 cm
Rack Height	2U	2U	2U
Weight	38.45 kg (84.77 lb)	39 kg	44.28 kg
Typical Run Time (at 500 Watt Average Draw)	58 minutes	40 minutes	38 minutes

# Safety & Compliance

This guide provides important safety information pertaining to the installation and operation of the DRAGEN Server. This guide includes product compliance and regulatory statements. Read this document before performing any procedures on the server.

The country of origin and date of manufacture of the server are printed on the server label.

## Safety Considerations and Markings

This section identifies potential hazards associated with installing, servicing, and operating the DRAGEN Server. Do not operate or interact with the DRAGEN Server in a manner that exposes you to any of these dangers.

### General Safety Warnings

Make sure that all personnel are trained in the correct operation of the DRAGEN Server and any potential safety considerations.



Follow all operating instructions when working in areas marked with this label to minimize risk to personnel or the DRAGEN Server.

### Electrical Safety Warnings

Do not remove the outer panels from the DRAGEN Server. There are no user-serviceable components inside. Operating the DRAGEN Server with any of the panels removed creates potential exposure to line voltage and DC voltages.

## Compliance and Regulatory Markings

The DRAGEN Server is labeled with the following compliance and regulatory markings.

### Waste Electrical & Electronic Equipment (WEEE)



This label indicates that the instrument meets the WEEE Directive for waste.

Visit [support.illumina.com/certificates.html](https://support.illumina.com/certificates.html) for guidance on recycling your equipment.

# Set Up the DRAGEN Server

This section provides information on installing the DRAGEN Server. Before beginning, make sure that you have all the components and your facility meets the requirements.

The following components are not included with the DRAGEN Server and required to set up the server:


- Monitor with a VGA input
- VGA cable
- Keyboard with a USB input
- Mouse with a USB input

## Mount the Server

Use the following instructions to mount the DRAGEN Server to your server rack.

### Attach Mounting Bracket to Server

1. Pull the mounting bracket rail out from the rail assembly until you reach the safety lock.
2. Press the yellow rail lock lever up, and then remove the mounting bracket rail from the rail assembly.





3. Align the key slots to the T studs on the sides of the server and slide the mounting bracket back to lock into place.




4. Repeat to attach the mounting bracket on the other side.

### Mount the Rail Assemblies in Rack

1. Press down on the rail assembly mechanism to unlock the rear rail assembly lock.
2. Align the rail assembly into the desired server rack brackets and push forward to lock into place. An audible click indicates that the rail assembly is in place.
3. Release the yellow locking latch and push the slider forward to the rear of the rail assembly.
4. Align the rail assembly into the desired front server rack brackets and flip the lock mechanism forward to lock the rail assembly into place.


5. Repeat for the other rail.



## Install the Server in the Rack

Two people are recommended for moving the server.


1. Facing the front of the rack, align the mounting brackets on the server with the slide rails inside the rack.
2. Slide the mounting brackets into the slide rails until you reach the safety locks.
3. Press both safety lock triggers down simultaneously and slide the server forward until it rests against the server rack.
4. Insert the required cables.
5. Insert screws into the rectangular window on the front of each lock mechanism.



## Server Ports

The following figure indicates the port location for each cable required when installing the Illumina DRAGEN Server.

Figure 1 Rear of DRAGEN Server



- A. VGA port (monitor)
- B. 1 GB Ethernet port with interface name enp5s0 (BMC)
- C. 1 GB Ethernet port with interface name enp4s0
- D. 10 GB Ethernet port with interface name enp26s0f1
- E. 10 GB Ethernet port with interface name enp26s0f0
- F. 10 GB SFP+ port with interface name enp135s0f0
- G. 10 GB SFP+ port with interface name enp135s0f1
- H. Power supply inlets

### Insert Cables

1. Using the VGA cable, attach the VGA monitor to the server VGA port.
2. Attach the USB keyboard to any open USB port.
3. Attach network cable RJ45 to network port C.

## Install the Illumina DRAGEN Server License

You can activate the DRAGEN Server by installing the USB license key as follows. You must activate the server before proceeding.

1. Connect the power supply to the AC inlet, and then to a wall outlet.
2. Locate the USB license key in the delivery box.
3. Plug the USB license key into any USB port on the back of the server.
4. Connect the power cord to the power supply inlet, and then to the wall outlet.
5. The server turns on automatically.

6. Connect your monitor to the DRAGEN Server using the VGA port.
7. Connect your keyboard to the DRAGEN Server using any unoccupied USB port.

## Shut Down the Server

You can shut down the DRAGEN Server directly from the command line.

1. Log in as root.
2. To initiate system shutdown, enter:

```
poweroff
```

Wait a few minutes until the server comes to a complete shutdown.

# Configure Settings

You can configure the following settings for the DRAGEN Server:

- Security
- Networking
- Baseboard management controller

## Security and Safety

The DRAGEN Server is designed to resist attacks. Supplement this design with the following security recommendations:

- A secure internal LAN to prevent the distribution of data to all web browsers.
- Limited access to the DRAGEN Server to prevent the removal of the RAID controller, disk drives, and access to data. Booting in single-user mode allows access to the whole system.
- The DRAGEN Server is designed to analyze sequencing data. Do not consider it a general-purpose computer. For quality and security reasons, do not use the computer for web browsing, checking email, reviewing documents, or other unnecessary activity. These activities can result in degraded performance or loss of data.

### Antivirus Software

Illumina does not recommend running any virus scanners on the DRAGEN Server. Virus scanners often impact the performance of High-Performance Computing (HPC) systems.

### Restricted Ports and Authentication

---

Outbound Connections	lus.edicogenome.com port 80
Inbound Connections	SSH: TCP port 22

---

### Stack Overflow Protection

Modern processors disable coded execution in data sections of the program to address stack overflow attacks. By default, this feature is enabled.

### User Behavior

The DRAGEN Server is designed for analyzing sequencing data. For quality and security reasons, it should not be used for general-purpose computing such as web browsing, checking email, or running third-party software. These activities can result in degraded performance or data loss. Users should

also avoid storing files on the scratch drive as it can impede the proper operation of the server.

## Network Considerations

Before running tests, make sure that your network contains the required components and meets the network connection recommendations.

DRAGEN Server setup requires the following network components:

- Default gateway address
- DNS Server IP address
- IP addresses (2)
- Subnet mask for the IP addresses

The following operations require an external internet connection using TCP on ports 80 and 443:

- Updating the software
- Remote assistance from Illumina Technical Support
- Access to license server

### Network Connections

Use the following recommendations to install and configure a network connection:

- Recommended bandwidth for a connection is 10 GB per second.
- Switches and other network equipment must have a minimum of 10 GB per second.
  - Calculate the total capacity of the workload on each network switch. The number of connected instruments and ancillary equipment, such as a printer, can impact capacity.
- For 10 GB connections, SFP+ and RJ45 connections are supported. If using SFP+ ports, twinax cables or SFP+ transceivers are required. Validated transceivers include Intel and Finisar.
- Ask your IT professional to review network maintenance activities for potential compatibility risks with the system.

## Configure the Server Network

Using the Network Manager Text User Interface (NMTUI), you can configure the IP address, gateway, DNS server, and additional options for your connection.

3. Login as root using the default password: `Hello@Illumina!`. The system will prompt users to reset the password upon first login.
4. Enter:

```
nmtui
```

5. Use your keyboard to navigate the NMTUI.

6. Select **Activate** a connection to view your active Ethernet connection.  
The active Ethernet connection shows an asterisk in front of the connection name.
7. Select **Back**.
8. Select **Edit** a connection.
9. Navigate to your active connection, and then select **Edit**.
10. Select **Show** next to **IPv4 Configuration** or **IPv6 Configuration**.
11. Select **Automatic** to choose one of the following IP configurations:
  - [To remove the IP configuration], select **Disabled**.
  - [To automatically obtain your IP address from DHCP], select **Automatic**.
  - [To manually set your IP address], select **Manual**.
12. Set the following network settings:
  - IP address and subnet mask
  - Gateway
  - DNS server
  - [Optional] Search domain
  - [Optional] Select additional routing settings depending on your routing configuration.
13. Select how users can access the connection.
  - **Automatically connection**—The connection acts as the default connection for all users.
  - **Available to all users**—All users can access this connection. Disabling this option removes the connection from the list of available connections for users.
14. Select **OK**.

## Set Server Time

### Set Server Time to Local Time Zone

1. Log in as root.
2. Check if the current server time reflects the local time zone using the `date` command. Enter:

```
date
```
3. Check for a nearby city with the correct time zone using the `timedatectl list-timezones` command.  
For example, use the following command to find time zones in Asia:

```
timedatectl list-timezones | grep Asia
```
4. Change the server time to local time using the `timedatectl set-timezone` command.

Example:

```
timedatectl set-timezone Asia/Singapore
```

5. To make sure that the server time has changed, enter:

```
ls -l /etc/localtime
```

## Synchronize Server Time to NTP Server

1. Log in as root.
2. Check if chrony daemon is running. Enter:

```
systemctl status chronyd
```

3. If the result from the previous command shows inactive or dead, enable the chrony daemon. Enter:

```
systemctl enable chronyd
```

4. To start the daemon, enter:

```
systemctl start chronyd
```

5. Edit /etc/chrony.conf using vi. Enter:

```
vi /etc/chrony.conf
```

6. Replace the default NTP server settings to the local NTP server.

Original default settings:

```
server 0.centos.pool.ntp.org iburst
server 1.centos.pool.ntp.org iburst
server 2.centos.pool.ntp.org iburst
server 3.centos.pool.ntp.org iburst
```

Settings to use local NTP server(s):

```
server 192.168.1.1 iburst
server 192.168.1.2 iburst
```

7. To save the file, enter:

```
:wq!
```

8. To restart the chrony daemon, enter:

```
systemctl restart chronyd
```

9. Check the health of the local time server. Enter:

```
timedatectl
```

10. Make sure that DRAGEN Server can synchronize with the local NTP server using one of the following commands:

- chronyc tracking (Manual)
- ntpdate (Automatic)

The following is an example command:

```
ntpdate -q 192.168.1.1
```

## Configure BMC

You can connect to the Baseboard Management Controller (BMC) to provide remote monitoring and control for Illumina Technical Support. Refer to [Server Ports on page 12](#) for the proper port to use.

1. Log in as root using the root password provided in the DRAGEN Server welcome email. If you have not received your sign in credentials, contact Illumina Customer Service.

2. If signing in for the first time, reset your password.

Passwords must contain at least 10 alphanumeric characters and two special characters.

3. To use a static IP address, do as follows.

a. Enter the following command:

```
ipmitool lan set 1 ipsrc static
```

b. To set the IP address, enter:

```
ipmitool lan set 1 ipaddr <IP address>
```

c. To set the netmask, enter:

```
ipmitool lan set 1 netmask <netmask ID>
```

d. To set the default gateway, enter:

```
ipmitool lan set 1 defgw ipaddr <gateway ID>
```

4. Enter the IP address into the web browser. You can sign in as an admin using the password printed on the back of the DRAGEN Server.

## Access the Server Remotely

To access your DRAGEN Server from a remote location, you must set your firewall zone to public and allow root login from SSH connections.

## Set Firewall Zone

By default, the firewall is enabled and blocks all incoming connections. To allow remote SSH connections, run the following script:

```
/usr/local/bin/mfg_enable_network.sh
```

This script accomplishes these steps:

- Sets firewall zone to public
- Sets network interfaces to automatically start when the server is turned on
- Allows users to log in via SSH
- Reloads the SSHD configuration
- Restarts the network manager service

## Allow Root Log in by SSH

To access the Illumina DRAGEN Server remotely, you must enable root log in by SSH connections. By default, root log in from SSH connections are blocked.

1. Log in as root.
2. Open `/etc/ssh/sshd_config`.
3. Set `PermitRootLogin` to `yes`.
4. Restart `sshd`. Enter:  

```
systemctl restart sshd
```

## Resources & References

The Local Run Manager support pages on the [Illumina support site](#) provide additional resources. These resources include training, compatible products, and other considerations. Always check support pages for the latest versions.

## Revision History

Document	Date	Description of Change
Document #200015717 v01	July 2022	Updated the server specifications. Added the server weight. Updated the UPS recommendations. Renamed Install the Server Racks to Mount Server.
Document #200015717 v00	June 2022	Initial Release



Illumina

5200 Illumina Way

San Diego, California 92122 U.S.A.

+1.800.809.ILMN (4566)

+1.858.202.4566 (outside North America)

[techsupport@illumina.com](mailto:techsupport@illumina.com)

[www.illumina.com](http://www.illumina.com)

**For Research Use Only. Not for use in diagnostic procedures.**

© 2022 Illumina, Inc. All rights reserved.

**illumina**<sup>®</sup>